


35. HORIZONT CURTAIN(W)
34. HORIZONT CURTAIN(B)
33. DRAW CURTAIN #4
32. SET BATTEN #10
31. UPPER LIGHT BATTEN
30. LIGHT BATTEN #4
29. SET BATTEN #15(H/C)
28. SET BATTEN #9
27. 정면 음향반사판
26. SCREEN
25. DRAW CURTAIN #3
24. SET BATTEN #14
23. SET BATTEN #8
22. LIGHT BATTEN #3
21. 측면 음향반사판 #3,4
20. 천정 음향반사판 #2

19. SET BATTEN #7
18. DRAW CURTAIN #2
17. SET BATTEN #13(H/C)

16. SET BATTEN #6
15. LIGHT BATTEN #2
14. SET BATTEN #12(H/C)
13. SET BATTEN #5
12. SET BATTEN #4
11. DRAW CURTAIN #1
10. 측면 음향반사판 #1,2
09. 천정 음향반사판 #1
08. SET BATTEN #3
07. LIGHT BATTEN #1
06. SET BATTEN #11(H/C)

05. SET BATTEN #2(수동 다리막 5M)
04. SET BATTEN #1
03. MAIN CURTAIN(UP-DN/OP-CL)

02. PLACARD BATTEN
01. APRON LIGHT BATTEN



축척 A3 : $\frac{1}{50}$ A4 : $\frac{1}{100}$

일자 2020 . 12. .

도면명

대공연장 무대장치 단면도

금정문화회관

(46251) 부산광역시 금정구 체육공원로 7 (구서동) TEL.051)519-5681
http://art.geumjeong.go.kr FAX.051)519-5659