

20.HORIZONT CURTAIN (W)

19.DRAW CURTAIN #3

18.SET BATTEN #7

17.UPPER HORI LIGHT BATTEN

16.정면 음향반사판

15.SCREEN

14.SET BATTEN #6

13.SET BATTEN #5

12.LIGHT BATTEN #2

11.DRAW CURTAIN #2

10.천정 음향반사판

09.SET BATTEN #4 (H/C)

08.SET BATTEN #3

07.SET BATTEN #2

06.LIGHT BATTEN #1


05.SET BATTEN #1 (H/C)

04.DRAW CURTAIN #1

03.MAIN CURTAIN(UP-DN/OP-CL)

02.APRON LIGHT BATTEN

01.PLACARD BATTEN



축척 A3 : $\frac{1}{50}$ A4 : $\frac{1}{100}$

일자 2020 . 12. .

도면명

소공연장 무대장치 단면도

C:\Users\???\Desktop\d78182e6f957225198d3afc79c0fae4f.jpg

금정문화회관

(46251) 부산광역시 금정구 체육공원로 7 (구서동) TEL.051)519-5681
http://art.geumjeong.go.kr FAX.051)519-5659